


78-1 VARIABLE SPEED HEAVY DUTY VIBRATOR OPERATING MANUAL



Made in the U.S.A. Since 1920

DO NOT DISCARD

IMPORTANT INSTRUCTIONS

WARNING!

FOR YOUR SAFETY PLEASE READ INSTRUCTIONS
BEFORE OPERATING TOOL & WEAR EYE PROTECTION

THANK YOU FOR PURCHASING A HANDLER PRODUCT

Thank you for purchasing a HANDLER's MODEL 78-1 VIBRATOR.

Thank you for purchasing a HANDLER Vibrator. Please open the package and inspect the contents. Should damage have occurred in transit, contact the freight forwarder IMMEDIATELY. Failure to report damage to the forwarder promptly will result in loss of your rights to claim possible damage to the product received. The 78-1 vibrator has been inspected and tested many times during the manufacturing process. The vibrator was found to function properly before it was shipped. If damage has occurred to your new vibrator, please follow the procedure listed, above. Make certain to retain all packing for inspection by the freight forwarders inspector.

OPERATION

Your 78-1 Vibrator is built to function on 115 Volts/60Hz current, only. Connect the cord set to a suitable grounded electrical outlet prior to activating the ON/OFF switch.

Place the 78-1 on a flat smooth surface. We recommend the vibrator is covered with a plastic cover to protect the vibrator. The soft rubber feet are designed to keep the vibrator in a constant location during use. Dusts and debris on the working surface may allow the 78-1 to slip and slide around on the counter top. Keep the counter area clean and dry to prevent this from occurring.

The 78-1 is designed with variable speed operation. Turn the ON/OFF switch (#2) to the desired speed to adjust the vibration to the desired frequency.

The 78-1 Vibrator is manufactured to vibrate various types of viscous compounds. After each vibrating process, remove the plug from the electrical connection and wipe off any excess compound from the surface of the vibrator with a soft cloth. It is not recommended that harsh sprays or cleaners are to be used for this process. These will damage your vibrator. Remember keep your 78-1 vibrator clean.

For questions concerning the Handler 78-1 or any Handler product, please contact us at the address listed below:

CAUTION!

BEFORE Connecting and Operating!

Unpack Accessories from Unit

For Your Protection EXAMINE THE GOODS.



PARTS AND INSTALLATION

NOTE:

Many technicians place a clear plastic bag over the vibrator to keep the vibrator clean, removing it when it becomes soiled.


WARNING!

- (1) DO NOT use the vibrator with wet hands.
- (2) DO NOT use the vibrator in wet areas.
- (3) KEEP vibrator clean for maximum efficiency.
- (4) READ ALL ACCOMPANYING SAFETY RULES.

By following the instructions, above, you will be assured of durable service from your Handler 78-1 Vibrator.

Should you have questions concerning the 78-1 or any Handler product, please contact us at:

HANDLER MFG. CO., INC. 612 NORTH AVENUE, EAST WESTFIELD, N.J. 07090 PHONE: 908-233-7796 FAX: 908-233-7340




- 1 Rubber Suction Feet
- 2 On/Off Variable speed switch
- 3 Rubber Top
- 4 Cord set



GROUNDING AND TOOL SAFETY

1. GROUNDING INSTRUCTIONS

This tool should be grounded while in use to protect the operator from electric shock. The tool is equipped with an approved three-conductor cord and three-prong grounding type plug to fit the proper grounding type receptacle. The green (or green and yellow) conductor in the cord is the grounding wire. Never connect the green (or green and yellow) wire to a live terminal. If your unit is for use on less than 150 volts, it has a plug that looks like that shown in sketch (A) in Figure 1. If it is for use on 150 to 250 volts, it has a plug that looks like that shown in sketch (B). Use of an extension cords or a 2 prong adapter is not recommended.



2. TOOL SAFETY INSTRUCTIONS

- 1. Keep Work Area Clean: Cluttered areas and benches invite accidents.
- Avoid Dangerous Equipment
 Don't expose power tools to rain.
 Don't use power tools in damp or wet locations. Keep work area well lit.
- 3. Keep Children Away
 All visitors should be kept safe distance
 from work area and appliance.
- 4. Store Idle Tools

 When not in use, tools should be stored in dry, high, and locked location out of the reach of children.
- 5. Don't Force Tool
 It will do the job better and be safe at
 the rate for which it was designed.
- Use Right Tool
 Don't force small tool or attachment to do the job of a heavy-duty tool.
- 7. Wear Proper Apparel
 Do not wear loose clothing or jewelry which
 may get caught in moving parts. Tie back
 long hair or use a proper hair net.

- 8. Use Safety Glasses
 Use safety glasses with all rotating tools.
 Also use a face or dust mask if cutting operation is dusty.
- 9. Don't Abuse Cord

 Never carry tool by cord or yank it to
 disconnect from receptacle. Keep cord
 from heat, oil, and sharp edges.
- Secure Work
 Use clamps or a vise to hold work. It's
 safer than using your hand and it frees
 both hands to operate tool.
- Don't Overreach
 Keep proper footing and balance at all times.
- 12. Maintain Tools with Care Keep tools sharp and clean for best and safest performance. Follow instructions for lubricating and changing accessories.
- 13. Disconnect Tools and TURN OFF.
 When not in use; before servicing; when changing accessories such as blades, bits, cutters, etc.
- Avoid Accidental Starting this and any other appliance. Be sure switch is OFF when plugging in.



IMPORTANT NOTICE

WHAT SHOULD YOU DO TO RETURN GOODS

- Our terms of sale are F.O.B. our plant. Handler makes every effort to insure the
 proper delivery of goods, but we cannot guarantee the carrier's performance. Each
 product is tested and inspected for proper performance prior to leaving our facility.
 The responsibility for damage in transit is the carrier's, whether it is visible damage
 or concealed damage.
- 2. Inspect this shipment IMMEDIATELY. Insist that visible damage or possible damage be written on the Delivery Receipt by the receiver.
- 3. Inspect the contents of your shipment within 24 hours of receipt. Using your copy of our packing list, check for piece count and accuracy immediately to insure proper billing.
- 4. If damage is discovered, save all crates, cartons and packaging material until an inspection has been made by an agent of the carrier.
- In case of damage, notify the delivering carrier IMMEDIATELY requesting that an
 inspection be made. Retain a copy of the inspection request for claim purposes.
 Failure to notify the freight carrier immediately will result in the loss of your rights
 to claim damage.
- 6. We have taken every precaution to insure safe arrival of your products. We cannot be responsible for negligence by another party.
- 7. The receiver of the goods must make claims for incorrectly shipped goods to the shipper within 15 days of receipt of delivery.

RETURNING GOODS

- 1. DO NOT return merchandise without our authorization. You must call first for a return authorization number.
- 2. We will not accept returned merchandise from the carrier unless our authorization NUMBER has been issued, and is clearly marked on the outside of the carton.
- 3. We will not accept goods (i.e. dust collectors) that are not cleaned and free of dust and debris. The merchandise will be shipped back. This is in compliance with OSHA regulations.

HANDLER MFG.
612 NORTH AVENUE EAST, WESTFIELD, NEW JERSEY 07090



WARRANTY

This HANDLER product is warranted to be free from defects in material and workmanship, when used under the conditions recommended by the manufacturer, and/or the purpose for which the product was intended, for a period of 12 months from the date of shipment from factory to job site of original owner. Products purchased from distributor warehouse stock are warranted for a period of 18 months from date of shipment from the manufacturer's warehouse.

In all cases, the full name and address of the distributor must be supplied, along with the name of the customer, product name and number, and serial number. A copy of the original invoice, showing date of purchase must accompany the warranty repair request.

This warranty will apply to equipment installed, operated and maintained in accordance with HANDLER procedures and recommendations.

During the life of this warranty, HANDLER will repair or replace (At HANDLER's option) free of charge. F.O.B. its plant, any defective part or assembly, if such defect occurred in normal service and was not due to apparent misuse, abuse, or accident.

Any warranty service performed in the field must be authorized by HANDLER MFG. Unauthorized service voids the warranty and any resulting charge will not be paid by HANDLER MFG.

HANDLER MFG. makes no other warranties or guarantees, expressed or implied. The merchantability of the components is expressly excluded. The manufacturer assumes no liability for indirect or consequential damages.

Detach or copy and mail back to the address below.

Customer Name:			
Address:			
City:		State:	Zip:
Model No.:		Serial No.:	
Distributor:			
Distributor's Address			_

Return to HANDLER

HANDLER MFG. 612 NORTH AVENUE EAST, PO BOX 520 WESTFIELD, NEW JERSEY 07090-0520